

TEKNOLOGI

K21 Kitchen Hand Wash



K21 Kitchen Hand Wash is a fragrance free liquid hand wash developed for use in food preparation and processing areas that combines the cleansing power of synthetic soaps with emollients that reduce the drying of the skin. When washing hands correctly, K21's rich moisturizing lather will remove dirt whilst leaving the hands fresh and soft with no transferable after smell and taste that

FEATURES

- No residual smell or taste.
- Free from triclosan and triclocarban.
- All round protection.
- Gentle on hands with moisturising emollients.

ACTIVE INGREDIENT

LABSA, CDEA, TEA, SLES, Moisturizer, Glycerine, Water

DIRECTION

1. Fill the reservoir in the M-Teknologi Hand Wash Dispenser with K21 Kitchen Hand Wash.
2. Dispense one pump of the K21 Kitchen Hand Wash onto the palms.
3. Lather them for 20 seconds on every part of your hands as per the M-Teknologi Hand Wash Guide.
4. Rinse hands well under running water.
5. Dry with M-Teknologi paper towel or air dry.

WARNING

For external use only.

- Avoid contact with eyes. Causes eye irritation.
- In case of contact with eyes rinse immediately with plenty of water and seek medical advice
- If swallowed/ingested seek medical advice immediately and show this container or label
- Use only as directed.

K21 Kitchen Hand Wash

